

# IMAGE ANALYSIS FOR MATERIAL SCIENCE

*From image properties to material properties (I)*


## Key ideas

- Motivation
- General procedure
- Technical details
- Small Example
- Limitations
- Big example with Github and Federico's code. Resources at Imdea.


# Motivation

How to analyze the microstructure of the materials from the images of our tests?


Porosity in CFRP tomography



Metallic Powder particles



Impact CFRP




## General procedure

1. Obtain a binary image.
2. Detect independent regions of interests.
3. Compute properties to the regions.
4. Relate the measured properties with functional aspects.


# General procedure

1. Obtain a binary image.

Gray scale. Pixel values =( 0 - 255/65535)



Binary. Pixel values =( 0 background  
1 regions )




*Avoid the term "black and white image" because it is ambiguous when google for questions.*



# General procedure

1. Obtain a binary image.
2. Detect independent regions of interests. Numbered ID for each region.

**Binary.** Pixel values = ( 0 - 1)




**Labels.** Gray levels. Pixel values = ( 0 background  
1 region number 1  
2 region... 2  
n regions )



*Avoid the term "black and white image" because it is ambiguous when google for questions.*

# General procedure

1. Obtain a binary image.
2. Detect independent regions of interests.  
Numbered ID for each region.
3. Compute properties of each region.



Common useful properties:


1. Area
2. Centroid
3. Long axis
4. Short axis
5. Coordinates of the region pixels.
6. Filled area
7. Bounding box




## General procedure

1. Obtain a binary image.
2. Detect independent regions of interests.  
Numbered ID for each region.
3. Compute properties of each region.
4. Relate with material properties

Examples:



Manufacturing process with the area  
and the long and short axis of pores



Filled area of the particles with quality  
of final product




## Technical details of the process

1. Absolute/ Relative paths
2. Image bit type.
3. Image formats. Raw and tiff.
4. Multichannel (RGB) or one channel.

# Technical details of the process

## 1. Absolute/ Relative paths

Example:



Absolute path:

"C:\Users\Juan Ignacio\Desktop\Folder1"

Relative path:

"\Folder1"

The reference is where the running file is located

# Technical details of the process

## 1. Image bit type

### 8 bit

- Unsigned raster: 0 - 255
- Signed raster: -128 a 127.

### 16 bit

- Unsigned raster: 0 - 65535
- Signed raster: -32767 - 32767.

Beware with the labels image when using 8-bit images, they only support 255 different regions

# Technical details of the process

## 1. Image formats. Raw and tiff.


- **Raw** contains minimally processed data from the image sensor.



No information of the size of the images, nor bit type, little endian....

*A pain in the neck when coding*

- **Tiff** contains all the information to open an image.



Most tiff readers do not admit images larger than 4 GB. (common in tomography)

Solution?

Divide and conquer. Save the volume image as a collection of frame tiff images